




SECTION thru  
MC-37 CORNICE  
SCALE: 3" = 1'-0"




LAP FLANGE DETAIL  
SCALE: FULL SCALE




BUILDING SECTION thru  
MC-37 CORNICE  
SCALE: 3" = 1'-0"




ELEVATION of  
MC-37 CORNICE @ 8'-0" L.  
SCALE: 1 1/2" = 1'-0"




ELEVATION of  
MC-37 90° OUTSIDE CORNER  
SCALE: 1 1/2" = 1'-0"



REFLECTED PLAN of  
MC-37 90° OUTSIDE CORNER  
SCALE: 1 1/2" = 1'-0"



ELEVATION of  
MC-37 90° INSIDE CORNER  
SCALE: 1 1/2" = 1'-0"



REFLECTED PLAN of  
MC-37 90° INSIDE CORNER  
SCALE: 1 1/2" = 1'-0"

- NOTES:
- 1) FRAMING SHOWN IS SUGGESTED ONLY AND MAY NEED TO BE VERIFIED BY A LICENSED P.E. IN THE STATE OF WHICH THE PROJECT IS BEING CONSTRUCTED
  - 2) (\*) INDICATES PIECES TO BE FIELD CUT TO LENGTH REQUIRED FROM SUPPLIED OVERSIZED LENGTH (THE FOLLOWING ACTUAL DIMENSION)
  - 3) ALL BLOCKING, SUPPORT FRAMING, FASTENERS, FLASHING AND SEALANTS ARE THE RESPONSIBILITY OF THE INSTALLER
  - 4) LIGHTLY SAND ALL FIBERGLASS AREAS TO RECEIVE CAULK, SEALANTS OR PAINT PRIOR TO APPLICATION IN ORDER TO REMOVE ANY WAX BUILD UP OR DIRT.

- INSTRUCTION FOR INSTALLATION OF FIBERGLASS CORNICE
1. Provide and install wood or galvanized frame blocking @ 16" x 24" O.C. per shop drawings. Notch or set back blocking by 3/16" where lap joint occurs.
  2. Typically, a cornice section will have a lap joint to the right side. Begin an elevation with the left corner of the building and march to the right.
  3. Prepare section for installation by sanding lap joint and countersinking holes where blocking occurs. Countersink should allow a #10 flathead screw to sit just below the gel-coat surface.
  4. Lay a bead of caulk on lap joint to be covered by section to be installed.
  5. In cold weather, allow 1/8" at joint for expansion.
  6. Attach cornice to blocking using #10 x 1 1/2" galvanized or stainless steel screws in countersinks @ 16" x 24" O.C.
  7. Finish seams with paintable caulk. (Paint after curing with matching color)
  8. Patch screw holes with material supplied by manufacturer.
- IF PAINTING OF THE CORNICE IS DESIRED, FOLLOW THE BELOW STEPS
1. Wipe down all cornice sections with wax and grease remover.
  2. Lightly sand the cornices to be painted.
  3. Wipe down cornices again with wax and grease remover.
  4. Prime cornices if desired (but not necessary). Prime areas that have any body work done on them.
  5. Paint cornice with at least an oil base paint. We recommend that a urethane base paint be used for best results.

QUANTITIES:

XX - MC-37 CORNICE SECTIONS @ 8'-0"

REFER TO ARCHITECTURAL DRAWINGS

Melton Classics		REVISIONS
SUBJECT	MC-37 FRP CORNICE	
PROJECT	XXXX	
CONTRACTOR	XXXX	APPROVAL
ARCHITECT		
ORDER NO.		
DRAWN BY		
RDS		
DATE		
XXXX		MC-37